



SOFTWARE UPDATE!

Updating the software for the Rivdom eVNG 2 cordless riveter is straightforward and quick to implement. **Please carry out the update as soon as possible!**



The included SD card is located in the USB adapter that is also supplied.



Download the necessary file, unzip and save it on the SD card.
(www.honsel.de/evng2-update/)



Disconnect the tool from the battery




Pull the trigger once.




Insert the SD card with the new file into the slot under the cover on the front of the tool.



Connect the battery to the tool.



Press and hold the **LEFT** and **RIGHT** button at the same time...



... and start the upload by pulling the trigger.
The LEFT/RIGHT buttons and the trigger can be released.



The upload progress is shown on the display. As long as the upload is active, the control LED lights up **BLUE**.
As soon as the blue color disappears, the software **update has been successfully completed**.

If you have any questions, please contact your **HONSEL** sales team.

www.honsel.de