

Assembly sets

Pos.	Pcs.	Article	Order number	Price
1		Assembly-set for BZ 9	321.101.205.000	
1	1	valve wrench	321.101.005.003	on inquires
2	1	repair stand	321.101.005.017	
3	1	delay cone 12	321.101.005.016	
4	1	expansion sleeve	321.101.005.002	
5	1	stepseal-receiver 14, down	321.101.005.009	
6	1	center ring long	321.101.005.019	
7	1	leading-in sleeve 12	321.101.005.006	
8	1	rear assambly wrench, for tools without suction	321.101.005.022	
9	1	wrench for hydraulic piston	321.101.005.030	
10	1	circlip pliers 12	321.101.005.021	
11	1	calibrating piston 14	321.101.005.012	
12	1	repair device	321.101.005.004	

Pos.	Pcs.	Article	Order number	Price
1		Assembly-set for BZ 11	321.101.305.000	
1	1	valve wrench	321.101.005.003	on inquires
2	1	repair stand	321.101.005.017	
3	1	delay cone 18	321.101.005.015	
4	1	expansion sleeve	321.101.005.002	
5	1	stepseal-receiver 12, down	321.101.005.008	
6	1	stepseal-receiver 18, upper	321.101.005.010	
7	1	center ring short	321.101.005.014	
8	1	leading-in sleeve 18	321.101.005.005	
9	1	wrench for the safty device BZ 11	321.101.005.031	
10	1	rear assambly wrench, for tools without suction	321.101.005.022	
11	1	circlip pliers 18	321.101.005.001	
12	1	vacuum manometer	321.101.005.018	
13	1	calibrating piston 15	321.101.005.013	
14	1	calibrating piston 12	321.101.005.011	
15	1	repair device	321.101.005.004	

Pos.	Pcs.	Article	Order number	Price
1		Assembly-set for BZ 101	321.101.405.000	
1	1	valve wrench	321.101.005.003	on inquires
2	1	repair stand	321.101.005.017	
3	1	delay cone 18	321.101.005.015	
4	1	expansion sleeve	321.101.005.002	
5	1	stepseal-receiver 12, down	321.101.005.008	
6	1	stepseal-receiver 18, upper	321.101.005.010	
7	1	center ring short	321.101.005.014	
8	1	leading-in sleeve 18	321.101.005.005	
9	1	rear assambly wrench, for tools without suction	321.101.005.022	
10	1	circlip pliers 18	321.101.005.001	
11	1	vacuum manometer	321.101.005.018	
12	1	calibrating piston 12	321.101.005.011	
13	1	repair device	321.101.005.004	
14	1	wrench for the safty device, plastic	321.101.005.029	

Assembly sets

Pos.	Pcs.	Article	Order number	Price
1		Assembly-set for BZ 121	321.101.505.000	
1	1	valve wrench	321.101.005.003	on inquires
2	1	repair stand	321.101.005.017	
3	1	delay cone 18	321.101.005.015	
4	1	expansion sleeve	321.101.005.002	
5	1	stepseal-receiver 12, down	321.101.005.008	
6	1	stepseal-receiver 18, upper	321.101.005.010	
7	1	center ring short	321.101.005.014	
8	1	leading-in sleeve 18	321.101.005.005	
9	1	rear assambly wrench, for tools without suction	321.101.005.022	
10	1	circlip pliers 18	321.101.005.001	
11	1	vacuum manometer	321.101.005.018	
12	1	calibrating piston 12	321.101.005.011	
13	1	repair device	321.101.005.004	
14	1	wrench for the safty device, plastic	321.101.005.029	

Pos.	Pcs.	Article	Order number	Price
1		Assembly-set for BZ 215	321.101.805.000	
1	1	valve wrench	321.101.005.003	on inquires
2	1	repair stand	321.101.005.017	
3	1	delay cone 18	321.101.005.015	
4	1	expansion sleeve	321.101.005.002	
5	1	stepseal-receiver 14, down	321.101.005.009	
6	1	stepseal-receiver 18, upper	321.101.005.010	
7	1	center ring short	321.101.005.014	
8	1	leading-in sleeve 18	321.101.005.005	
9	1	circlip pliers 18	321.101.005.001	
10	1	vacuum manometer	321.101.005.018	
11	1	calibrating piston 15	321.101.005.013	
12	1	repair device	321.101.005.004	
13	1	wrench for the safty device, plastic	321.101.005.029	

Pos.	Pcs.	Article	Order number	Price
1		Assembly-set for BZ 221	321.101.605.000	
1	1	valve wrench	321.101.005.003	on inquires
2	1	repair stand	321.101.005.017	
3	1	delay cone 18	321.101.005.015	
4	1	expansion sleeve	321.101.005.002	
5	1	stepseal-receiver 14, down	321.101.005.009	
6	1	stepseal-receiver 18, upper	321.101.005.010	
7	1	center ring short	321.101.005.014	
8	1	leading-in sleeve 18	321.101.005.005	
9	1	circlip pliers 18	321.101.005.001	
10	1	vacuum manometer	321.101.005.018	
11	1	calibrating piston 14	321.101.005.012	
12	1	repair device	321.101.005.004	
13	1	wrench for the safty device, plastic	321.101.005.029	